

SEESAW

JUMP



**HILARIOUS FUN
WITH
SEESAW JUMP!**

SEGA

SEESAW JUMP

The Seesaw Jump is a 1 or 2 player game where comical clowns bounce each other off a seesaw to burst balloons flowing in 3 rows across the top of the screen.

Player must be adept to catch the falling clown with the empty side of the seesaw by turning the knob at the front. The higher the clown bounces, the more balloons he will burst.

Features

Optional choice of balloon reset – single row reset or 3 row reset.

Height of bounce varies according to the place on the seesaw where the clown lands.

Speed of bounce increases as more balloons are burst.
Bonus scores won by bursting all balloons in one row.
Bonus Jump won by bursting all of the blue balloons.
1 Credit won by topping the high score on the screen.

5 Sound effects: Music at beginning of game Bouncing sound, thud of clown missing seesaw and falling to the ground, bursting of the balloons, and fanfare when a row of balloons are burst.

Coinage: Adjustable 1 or 2 coins per play

Size: W68cm × D76cm × H168cm

Monitor: 23" Black & White

Cabinet: Decorative polyester panels

SEGA

Sega Enterprises, Ltd.
P.O. Box 63 Tokyo Airport Post Office
Tokyo 149 Japan TEL. 03-742-3171
TWX: J22357 Cable: Segastar