Retro-Bit® SEGA Controller	Region Availability	Connector	SKUs	SEGA Genesis® / Mega Drive consoles	SEGA Saturn® consoles	SEGA Genesis® / Mega Drive Mini	PC (Windows® 10)	Mac® (Mojave+)	Android® (4.0+)	Steam®	PS3®	PS4®	Xbox One®	Switch	PC Engine® Mini / TurboGrafx-16® Mini	RetroPie®	Super Retro-Cade	Super Retro-Trio
SEGA Genesis® 6-Button Arcade Pad - Original Port	North America	Genesis® / Mega Drive	RB-SGA-001 RB-SGA-002 RB-SGA-041	OK														OK
SEGA Saturn® Control Pad - Original Port	North America	Saturn®	RB-SGA-020 RB-SGA-022 RB-SGA-043		OK													
SEGA Genesis® 8-Button Arcade Pad with USB® (Model 1)	North America	USB®	RB-SGA-003 RB-SGA-004			OK	OK	OK	OK	OK	OK	Via Brook PS3-PS4 Converter	Via Brook XBox PS3/4-Xbox One Converter	Via Mayflash Magic-NS	OK	OK	OK	
SEGA Genesis® 8-Button Arcade Pad with USB® (Model 2)	North America	USB®	RB-SGA-003 RB-SGA-004 RB-SGA-042			OK	OK	OK	OK	OK	OK	Via Brook PS3-PS4 Converter	Via Brook XBox PS3/4-Xbox One Converter	OK	OK	OK	OK	
SEGA Genesis® 6-Button Arcade Pad with USB® (Designed for the Genesis® Mini)	North America	USB®	RB-SGA-034 RB-SGA-035			OK	OK	OK	OK	OK	OK			OK	OK	OK	OK	
SEGA Saturn® Control Pad with USB® (Model 1)	North America	USB®	RB-SGA-023 RB-SGA-024			OK	OK	OK	OK	OK	OK	Via Brook PS3-PS4 Converter	Via Brook XBox PS3/4-Xbox One Converter	Via Mayflash Magic-NS	OK	OK	OK	
SEGA Saturn® Control Pad with USB® (Model 2)	North America	USB®	RB-SGA-023 RB-SGA-024			OK	OK	OK	OK	OK	OK	Via Brook PS3-PS4 Converter	Via Brook XBox PS3/4-Xbox One Converter	OK	OK	OK	OK	
Retro-Bit 2.4 GHz Wireless Receiver for SEGA Genesis®/Mega Drive	North America	Genesis® / Mega Drive	RB-SGA-046	OK														OK
Retro-Bit 2.4 GHz Wireless Receiver for SEGA Saturn®	North America	Saturn®	RB-SGA-045		OK													
Retro-Bit 2.4 GHz Wireless USB® Receiver	North America	USB®	RB-UNI-1984			OK	OK	OK	OK	OK	OK	Via Brook PS3-PS4 Converter	Via Brook XBox PS3/4-Xbox One Converter	OK	OK	OK	OK	
SEGA Genesis® 8-Button Wireless Arcade Pad ft. Bluetooth® technology (Wireless)	North America	Bluetooth®	RB-SGA-011 RB-SGA-012	Via Bluetooth Receiver for Genesis/Mega Drive	Via Bluetooth Receiver for Saturn		OK	OK	OK	OK				OK		May vary on model & installed program.		Via Bluetooth Receiver for Genesis/Mega Drive
SEGA Genesis® 8-Button Wireless Arcade Pad ft. Bluetooth® technology (Wired)	North America	USB®	RB-SGA-011 RB-SGA-012			Charge Mode	OK	Charge Mode	OK	OK	OK	Via Brook PS3-PS4 Converter	Via Brook XBox PS3/4-Xbox One Converter	OK		May vary on model & installed program.		
SEGA Saturn® Control Pad ft. Bluetooth® technology (Wireless)	North America	Bluetooth®	RB-SGA-029 RB-SGA-030	Via Bluetooth Receiver for Genesis/Mega Drive	Via Bluetooth Receiver for Saturn		OK	OK	OK	OK				OK		May vary on model & installed program.		Via Bluetooth Receiver for Genesis/Mega Drive
SEGA Saturn® Control Pad ft. Bluetooth® technology (Wired)	North America	USB®	RB-SGA-029 RB-SGA-030			Charge Mode	OK	Charge Mode	OK	OK	OK	Via Brook PS3-PS4 Converter	Via Brook XBox PS3/4-Xbox One Converter	OK		May vary on model & installed program.		
Retro-Bit Bluetooth Wireless Receiver for SEGA Genesis®/Mega Drive	North America	Genesis® / Mega Drive	RB-SGA-010	OK														OK
Retro-Bit Bluetooth Wireless Receiver for SEGA Saturn®	North America	Saturn®	RB-SGA-027		OK													

Retro-Bit® SEGA Controller	Region Availability	Connector	SKUs	SEGA Genesis® / Mega Drive consoles	SEGA Saturn® consoles	SEGA Genesis® / Mega Drive Mini	PC (Windows® 10)	Mac® (Mojave+)	Android® (4.0+)	Steam®	PS3®	PS4®	Xbox One®	Switch	PC Engine® Mini / TurboGrafx-16® Mini	RetroPie®	Super Retro-Cade	Super Retro-Trio
SEGA® Mega Drive 6-Button Arcade Pad - Original Port	Europe	Genesis® / Mega Drive	RET00123 RET00124	OK														OK
SEGA Saturn® Control Pad - Original Port	Europe	Saturn®	RET00129 RET00131		OK													
SEGA® Mega Drive 8-Button Arcade Pad with USB® (Model 1)	Europe	USB®	RET00125 RET00126			OK	OK	OK	OK	OK	OK	Via Brook PS3-PS4 Converter	Via Brook XBox PS3/4-Xbox One Converter	Via Mayflash Magic-NS	OK	OK	OK	
SEGA® Mega Drive 8-Button Arcade Pad with USB® (Model 2)	Europe	USB®	RET00125 RET00126			OK	OK	OK	OK	OK	OK	Via Brook PS3-PS4 Converter	Via Brook XBox PS3/4-Xbox One Converter	OK	OK	OK	OK	
SEGA® Mega Drive 6-Button Arcade Pad with USB® (Designed for the Mega Drive Mini)	Europe	USB®	RET00158 RET00159			OK	OK	OK	OK	OK	OK			OK	OK	OK	OK	
SEGA Saturn® Control Pad with USB® (Model 1)	Europe	USB®	RET00132 RET00134			OK	OK	OK	OK	OK	OK	Via Brook PS3-PS4 Converter	Via Brook XBox PS3/4-Xbox One Converter	Via Mayflash Magic-NS	OK	OK	OK	
SEGA Saturn® Control Pad with USB® (Model 2)	Europe	USB®	RET00132 RET00134			OK	OK	OK	OK	OK	OK	Via Brook PS3-PS4 Converter	Via Brook XBox PS3/4-Xbox One Converter	OK	OK	OK	OK	
Retro-Bit 2.4 GHz Wireless Receiver for SEGA Genesis®/Mega Drive	Europe	Genesis® / Mega Drive		OK														OK
Retro-Bit 2.4 GHz Wireless Receiver for SEGA Saturn®	Europe	Saturn®			OK													
Retro-Bit 2.4 GHz Wireless USB® Receiver	Europe	USB®				OK	OK	OK	OK	OK	OK	Via Brook PS3-PS4 Converter	Via Brook XBox PS3/4-Xbox One Converter	OK	OK	OK	OK	
SEGA® Mega Drive 8-Button Wireless Arcade Pad ft. Bluetooth® technology (Wireless)	Europe	Bluetooth®	RET00142 RET00143	Via Bluetooth Receiver for Genesis/Mega Drive	Via Bluetooth Receiver for Saturn		OK	OK	OK	OK				OK		May vary on model & installed program.		Via Bluetooth Receiver for Genesis/Mega Drive
SEGA® Mega Drive 8-Button Wireless Arcade Pad ft. Bluetooth® technology (Wired)	Europe	USB®	RET00142 RET00143			Charge Mode	OK	Charge Mode	OK	OK	OK	Via Brook PS3-PS4 Converter	Via Brook XBox PS3/4-Xbox One Converter	OK		May vary on model & installed program.		
SEGA Saturn 8-Button Wireless Arcade Pad ft. Bluetooth® technology (Wireless)	Europe	Bluetooth®	RET00145 RET00146	Via Bluetooth Receiver for Genesis/Mega Drive	Via Bluetooth Receiver for Saturn		OK	OK	OK	OK				OK		May vary on model & installed program.		Via Bluetooth Receiver for Genesis/Mega Drive
SEGA Saturn 8-Button Wireless Arcade Pad ft. Bluetooth® technology (Wired)	Europe	USB®	RET00145 RET00146			Charge Mode	OK	Charge Mode	OK	OK	OK	Via Brook PS3-PS4 Converter	Via Brook XBox PS3/4-Xbox One Converter	OK		May vary on model & installed program.		
Retro-Bit Bluetooth Wireless Receiver for SEGA Genesis®/Mega Drive	Europe	Genesis® / Mega Drive	RET00128	OK														OK
Retro-Bit Bluetooth Wireless Receiver for SEGA Saturn®	Europe	Saturn®	RET00136		OK													